

VW • AUDI

1. Located under the dust cover of the gear lever or at right side of upper cover of gear lever. Remove the dust cover, you will see a 16-pole diagnostic socket. Plug VW • AUDI adapter Cable (16-pole) for the tool into the diagnostic socket.




Figure 1

2. Located at left up corner of the engine compartment, in the fuse box. Open the fuse box, you will see a black 2-pole diagnostic socket.

3. The black 2-pin diagnostic socket is power socket, plug black terminal of adapter cable (2-pole) for the tool into it. The white 2-pole diagnostic socket is signal socket. Plug white terminal of adapter cable (2-pole) into it.




Figure 2

VOLVO

1. Located at the left side of engine compartment, beside damper column.
2. Plug terminal of VOLVO adapter cable (1-pole) into No "7" pole of diagnostic socket A.
3. Clip red power clamp of VOLVO adapter cable to copper sheet or copper wire at positive terminal of vehicle battery (B+).
4. Clip black power clamp of VOLVO adapter cable to copper sheet or copper wire at negative terminal of vehicle battery (B-).

