



Mercedes-Benz

## MERCEDES-BENZ® 1987-2010

VERSION: 2011.04 DATE: Apr. 26<sup>th</sup>, 2011

### AVAILABLE MODELS LIST

MODELS	CHASSIS TYPE
A-class	168, 169
B-class	245
C-class	201, 202, 203, <b>203-CAN, 204</b>
E-class	124, 210, <b>211, 212, 207(coupe)</b>
S-class	126, 140, <b>220, 220-CAN, 221</b>
SLK-class	170, <b>171</b>
CLK-class	208, <b>209</b>
SL-class	107, 129, 230, <b>230-CAN</b>
CLS-class	219
CL-class	<b>215, 215-CAN, 216</b>
R-class	<b>251</b>
M-class	163, <b>164</b>
G-class	463
GL-class	<b>X164</b>
V-class and Transporter	<b>SPRINTER, VITO, Vaneo, VITO, VIANO, SPRINTER906</b>

\* If the models are not listed here, users could select the related models.

## A-class, 168 with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ECM/MSM (Engine Control Monolith)	✓	✓	✓	✓	
CDI 1 (Common Rail Diesel Injection)		✓			
ACS (Automatic Clutch System)	✓	✓			
FTC (Front Transmission Control)	✓	✓			
GRM (Gear Recognition Module)		✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Thief Alarm)	✓	✓			
LCP (Lower Control)	✓	✓	✓		
RFL (Radio Frequency Locking)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓	✓		
DCM 2	✓	✓	✓		
DCM 3	✓	✓	✓		
DCM 4	✓	✓	✓		

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

\*QUICK SERVICE: Perform "Service Reset" within seconds.

## A-class, 169 with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
FCVT (Continuously variable automatic transmission)	✓	✓			
SIM266 (Engine system)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
FCVT	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ES (Electrical power steering)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
CGW (Central gateway)		✓			
EIS (Electronic ignition switch, without Keyless Go)	✓	✓			
OCP (Overhead control panel)	✓	✓			
SAM (Signal acquisition and actuation module)	✓	✓			
HRA-FL		✓			
HRA-FR		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset	
PTS (Parktronic System)	✓	✓			
SCM(Steering column module)	✓	✓			
ASSYST-PLUS		✓		Service Reset	

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL		✓			
DCM RR		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	✓	✓			

## B-class, 245 with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
FCVT (Continuously variable automatic transmission)	✓	✓			
SIM266 (Engine system)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ES (Electrical power steering)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
CGW (Central gateway)	✓	✓			
EIS (Electronic ignition switch, without Keyless Go)	✓	✓			
OCP (Overhead control panel)	✓	✓			
SAM (Signal acquisition and actuation module)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset	
ASSYST PLUS (PLUS Active Service System)	✓	✓		Service Reset	
PTS (Parktronic System)	✓	✓			
SCM(Steering column module)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓			
DCM 2	✓	✓			
DCM 3	✓	✓			
DCM 4	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	✓	✓	✓	✓	

## C-class, 201

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CIS-E		✓			
ELR (Diesel Injection Electronic ISC)		✓			
ESCM		✓			
ASD (Automatic Locking Differential)		✓			
AB (SRS / Airbag)		✓			
Climate Control		✓			

## C-class, 202

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			

## C-class, 202 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
ATA (Anti-Thief Alarm)	✓ (before 97)	✓			
PSE	✓ (before 97)	✓			
SAM	✓	✓	✓	✓	
OCP	✓	✓	✓		
LCP (Lower Control)	✓	✓	✓		
HRA		✓			
SVMCM		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓			
DCM 2	✓	✓			
DCM 3	✓	✓			
DCM 4	✓	✓			
ESA-FL		✓			
ESA-FR		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## C-class, 203-CAN with \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
<b>ME 9.7</b>	✓	✓	✓	✓	
SIM4LE	✓	✓		✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
<b>CDI 3</b>		✓			
<b>CDI 4</b>		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓	✓	✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (keyless)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
LCP (Lower Control)	✓	✓			
UCP (Upper Control)	✓	✓			
HRA-FL	✓	✓			
HRA-FR		✓			
<b>WSS (Weight Sensing System)</b>	✓	✓		✓	
AHE (Trailer recognition)		✓			
SVMCM		✓			

\*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

## C-class, 203-CAN with \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓ (more workshop functions)	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

  

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			

## C-class, 203 (non-CAN) with \*QUICK SERVICE and \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
SIM4LE	✓	✓		✓	
<b>SIM4LSE</b>	✓	✓		✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2 (Common Rail Diesel Injection)	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
KG (keyless Go)	✓	✓			
PSE	✓ (before 97)	✓			
SAM-FRONT	✓	✓	✓	✓	
SAM-REAR	✓	✓		✓	
OCP	✓	✓		✓	
LCP	✓	✓			
UCP	✓	✓			
HRA-FL	✓	✓			
HRA-FR		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

\*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

\*QUICK SERVICE: Perform "Service Reset" within seconds.

## C-class, 203 (non-CAN) with QUICK SERVICE & SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓	✓	✓ (more workshop functions)	✓
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓ (include TV on Drive)	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID / E-Call		✓			
TV		✓			
SOUND		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passneger	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC / HEAT	✓	✓	✓	✓	
REAR AC		✓			
STH (Stationary Heater)	✓	✓			

## C-class, 204 with \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
<b>ME 9.7</b>	✓	✓	✓	✓	
SIM271	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
<b>CDI 3</b>		✓			
<b>CDI 4</b>		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR(Adaptive Brake)	✓	✓			
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
OCP	✓	✓	✓		
COU	✓	✓			
WSS (Weight Sensing System)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
XALWA-L		✓			
XALWA-R		✓			
KG	✓	✓			

\*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

## C-class, 204 with \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓	✓		
RFK	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓	✓		
ESA – Passenger		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓		

## E-class, 124

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓ (digital mode only)	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓ (digital mode only)	✓	✓		
BM	✓ (digital mode only)	✓		✓	
CFI/CIS		✓			
ESCM		✓			
DI		✓			
ELR (Diesel Injection)		✓			
IFI / ERE (Electronic Inline injection)	✓	✓			
EDS (Electronic Diesel System)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ASD (Automatic Locking Differential)		✓			
4MATIC (4-Wheel Drive)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	
RCL (DAS2, Code 888)		✓			
CST		✓			
ATA	✓	✓			

CLIMATE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CLIMATE (Air conditioning)		✓			

## E-class, 210 with QUICK SERVICE & SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
SIM4LE	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
CDI 2	✓	✓	✓		
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			
VP (Vacuum Pump Brake Booster)	✓	✓			
SPS (Speed Sensitive Power Steering)		✓			
TPC (Tire Pressure monitor)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
ATA (Anti-Theft Alarm)	✓ (before 97)	✓	✓		
KFB	✓	✓			
PSE	✓	✓			
SAM	✓	✓	✓	✓	
OCP	✓	✓	✓		
LCP (Lower Control)	✓	✓	✓		
HRA		✓			
SVMCM		✓			
RCL/RFL		✓			

## E-class, 210 (cont.)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			
ICS		✓			
TV (TV tuner)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓		✓	
DCM 2	✓	✓		✓	
DCM 3	✓	✓		✓	
DCM 4	✓	✓		✓	
ESA-FL	✓	✓			
ESA-FR	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## E-class, 211-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
<b>ME 9.7</b>	✓	✓	✓	✓	
SIM4LE	✓	✓			
<b>SIM4LSE</b>	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
DTR (Distronic) CAN version		✓			
CDI 2	✓	✓	✓		
<b>CDI 3</b>		✓			
<b>CDI 4</b>		✓			
<b>CDI 5</b>		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic	✓	✓		✓	
TPC	✓	✓			
SBC	✓	✓		✓	
ABR	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓		✓	
EIS (Electronic Ignition Switch) and KG	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
SAM-Drive	✓	✓	✓	✓	
SAM-Passenger	✓	✓	✓	✓	
SAM-Rear	✓	✓	✓	✓	
OCP	✓	✓		✓	
LCP (Lower Control)	✓	✓			
UCP (Upper Control)	✓	✓			
HRA	✓	✓			
RevETR-LF		✓			
RevETR-RF		✓			
WSS (Weight Sensing System)	✓	✓		✓	
BCM (Battery control module)	✓	✓			
AHE	✓	✓			
<b>System Diagnosis</b>		✓			
<b>XALWA-L</b>	✓	✓			
<b>XALWA-R</b>	✓	✓			

## E-class, 211-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		✓	
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
TLC (Trunk Lid Control)	✓	✓			
HS (Seat Heater)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
HSW	✓	✓			
STH	✓	✓			

\*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

\*QUICK SERVICE: Perform “Service Reset” within seconds.

## E-class, 212-CAN with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ESM (Electronic Selector Module)	✓	✓			
ISM (Intelligent servo module)	✓	✓			
SGR(Radar sensors control unit)		✓			
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic		✓			
TPM	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
XALWA-L	✓	✓			
XALWA-R	✓	✓			
WSS (Weight Sensing System)	✓	✓			
OCP	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
PSD(Panoramic sliding roof)	✓	✓			
AHE		✓			
KDS(Trunk lid control)	✓	✓			
SG-FOND(Rear control unit)		✓			
SVMCM		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		OIL RESET	
SCM (Steering Column Module)	✓	✓			
DSI(DIRECT SELECT interface)		✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
NSA(Night View Assist)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU]( Audio/COMAND operating unit)	✓	✓			
MOST – ZAN( Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
AMKS-LF– Active multicontour seat (Driver)	✓	✓			
AMKS-RF - Active multicontour seat (Passenger)	✓	✓			
PPAMKS - Pneumatic pump for active multicontour seat	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓			
LRH[HSW] (Heated steering wheel)		✓			

## E-class(Coupe), 207-CAN with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ESM (Electronic Selector Module)	✓	✓			
SGR(Radar sensors control unit)		✓			
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)		✓			
ADS ( Adaptive damping system)	✓	✓			
TPC	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
XALWA-L	✓	✓			
XALWA-R	✓	✓			
WSS (Weight Sensing System)	✓	✓			
OCP	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
AHE	✓	✓			
SVMCM	✓	✓			
SG-FOND(Rear control unit)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		OIL RESET	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU]( Audio/COMAND operating unit)	✓	✓			
MOST – ZAN( Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM L	✓	✓			
DCM R	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓			

## S-class, 126

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
Engine ESCM		✓			
Engine CFI		✓			
ELR (Diesel Injection Electronic ISC)		✓			
EDS (Electronic Diesel System)		✓			
ASD (Automatic Locking Differential)		✓			
AB (SRS / Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	
Climate Control		✓			

## S-class, 140 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI / LH-SFI LEFT	✓	✓	✓	✓	
LH-SFI RIGHT	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
ME 1.0 LEFT BANK	✓	✓	✓	✓	✓
ME 1.0 RIGHT BANK	✓	✓	✓	✓	✓
ME 1.0 V8	✓	✓	✓	✓	✓
ME 2.0 / 2.1	✓	✓	✓	✓	✓
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
BM	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
IFI / ERE (Electronic Inline injection)	✓	✓			
DI		✓			
EDS		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
SPS (Speed Sensitive Power-Steering)		✓			
ASD (Automatic Locking Differential)		✓			
ADS (Adaptive Damping System)		✓			

## S-class, 140 with SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
IC (Instrument Cluster)	✓	✓		✓	
ATA (Anti-Thief Alarm)	✓	✓			
IRC(IR Controller)		✓			
RCL(DAS1/X)		✓			
RFL(DAS2/X)		✓			
CF/KFB		✓			
PSE	✓	✓			
HRA	✓	✓			
PTS	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAU (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## S-class, 221-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
SGR (Radar sensors control unit)		✓			
CDI 5		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	✓	✓			
AIRmatic (Suspension)	✓	✓	✓		
EPB (Electronic parking brake)	✓	✓			
TPC (Tire Pressure)	✓	✓			

## S-class, 221-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
XALWA-L (Left headlamp)	✓	✓			
XALWA-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-Driver	✓	✓		✓	
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
COU – ZBE (Central operating unit)	✓	✓			
HBF (Rear control field / panel)		✓			
System Diagnosis		✓			
BNS (Vehicle power supply control module)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

## S-class, 221-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)		✓			
DS-FR (Front Right Dynamic Seat)		✓			
DSP (Pneumatic pump for Dynamic Seat)		✓			
MKL-HL (Rear left Multicontour backrest)		✓			
MKL-HR (Rear right Multicontour backrest)		✓			
TLC (Truck lid control)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
NSA (Night View Assist)	✓	✓			
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
RFK (Backup camera)	✓	✓			
COMAND		✓			
ZAN (Central Display)		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KBE-H (Rear A/C operating unit)	✓	✓			
STH (Stationary Heater)		✓			

## S-class, 220-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
<b>ME 9.7</b>	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		
<b>CDI 3</b>		✓			
<b>CDI 4</b>		✓			

  

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓	✓	✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

## S-class, 220-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓		✓	
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA	✓	✓			
HLCM-L (Left headlamp)	✓	✓			
HLCM-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)	✓	✓		✓	
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
<b>System Diagnosis</b>		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

## S-class, 220-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KLA (Climate Control)	✓	✓	✓		
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

## S-class, 220 (non-CAN) with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓	✓	✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)	✓	✓		✓	
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

## S-class, 220 (non-CAN) with \*QUICK SERVICE & \*SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KLA (Climate Control)	✓	✓	✓		
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

## SLK-class, 170

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Thief Alarm)	✓	✓			
RFL		✓			
RFL / DAS2		✓			
HRA		✓			
VR	✓	✓	✓		
PSE	✓	✓			
CCM	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			

## SLK-class, 170 (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	✓	✓			

## SLK-class, 171-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
<b>ME 9.7</b>	✓	✓	✓	✓	
SIM4LE	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless)	✓	✓			
AB (SRS / Airbag)	✓	✓			
VR	✓	✓			
HRA		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
<b>System Diagnosis</b>		✓			

## SLK-class, 171-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)		✓			
ASSYST (Active Service System)	✓	✓		✓	
ASSYST PLUS (PLUS Active Service System)		✓		✓(Service Reset)	
SCM (Steering Column Module)		✓			
PTS (Parktronic System)		✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

  

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
HS (Seat heater)	✓	✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓	✓	✓	

## CLK-class, 208

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
DTR		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
HRA-FL	✓ (partial)	✓			
HRA-FR	✓ (partial)	✓			
UCP	✓	✓			
LCP (Lower Control)		✓			
SAM-FRONT	✓	✓		✓	
SAM-REAR	✓	✓		✓	
AHE (Trailer recognition)		✓			
RVC(Rollover bar soft top control module)	✓	✓	✓		

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TV (TV tuner)		✓			
SOUND		✓			

## CLK-class, 208 (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓			
DCM RIGHT	✓	✓			
DCM REAR		✓			
ESA LEFT	✓	✓			
ESA RIGHT	✓	✓			
TLC		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## CLK-class, 209

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
DTR		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
HRA-FL	✓	✓			
HRA-FR	✓	✓			
OCP	✓	✓			
UCP	✓	✓			
LCP (Lower Control)	✓	✓			
SAM-FRONT	✓	✓		✓	
SAM-REAR	✓	✓		✓	
AHE (Trailer recognition)		✓			
RVC	✓	✓			

## CLK-class, 209 (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TV (TV tuner)		✓			
SOUND		✓			

  

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓			
DCM RIGHT	✓	✓			
DCM REAR		✓			
ESA LEFT	✓	✓			
ESA RIGHT	✓	✓			
TLC		✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	✓	✓	✓ (partial version)	✓ (partial version)	
STH (Stationary Heater) (non-CAN)	✓	✓			

## SL-class, 107

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENGINE-CFI		✓			
AB (SRS / Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	

## SL-class, 129

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
BM	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
CFI		✓			
DI		✓			
CDI 2	✓	✓			
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			
ASD (Automatic Locking Differential)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
IR (IR controller)		✓			
ATA (Anti-Thief Alarm)	✓ (before 97)	✓			
RFL		✓			
RCL (DAS2/X)		✓			
APS		✓			
RB		✓			
RST		✓			
HRA		✓			

## SL-class, 129

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CTEL1 (Cellular Telephone 1)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## SL-class, 230

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
SBC	✓	✓		✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – LEFT	✓	✓			
ESA – RIGHT	✓	✓			
OSB-FL (Multicontour backrest Left)	✓	✓			
OSB-FR (Multicontour backrest Right)	✓	✓			

## SL-class, 230 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA-Front Right		✓			
HRA-Front Left		✓			
KG (keyless Go)	✓	✓			
SAM-Driver Side	✓	✓		✓	
SAM-Passenger Side	✓	✓			
SAM-Rear	✓	✓		✓	
PSE	✓	✓			
OCP	✓	✓			
LCP (Lower Control)	✓	✓	✓		
BNS (Vehicle power supply module)		✓			
RVC (Rollover bar / Vario Roof)	✓	✓	✓		
System Diagnosis		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TELE AID		✓			
D2B – TV (TV Tuner)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## SL-class, 230-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
<b>ME 9.7</b>	✓	✓	✓	✓	
ME 2.8 / <b>2.8 AMG</b>	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)		✓			
SBC	✓	✓	✓		
ABC (Active Body Control)		✓			
TPC (Tire Pressure)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – LEFT	✓	✓			
ESA – RIGHT	✓	✓			
OSB-FL (Multicontour backrest Left)	✓	✓			
OSB-FR (Multicontour backrest Right)	✓	✓			

## SL-class, 230-CAN(continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW		✓			
WSS	✓	✓		✓	
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)		✓			
HRA-Front Right		✓			
HRA-Front Left		✓			
KG (keyless Go)		✓			
SAM-Driver Side	✓	✓		✓	
SAM-Passenger Side	✓	✓			
SAM-Rear	✓	✓		✓	
PSE	✓	✓			
OCP	✓	✓			
LCP (Lower Control)	✓	✓	✓		
BNS (Vehicle power supply module)		✓			
RVC (Rollover bar / Vario Roof)	✓	✓	✓		
System Diagnosis		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TELE AID		✓			
D2B – TV (TV Tuner)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## CLS-class, 219-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
<b>ME 9.7</b>	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 4		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRMatic	✓	✓			
SBC	✓	✓		✓	
TPC	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG(keyless)	✓	✓			
AB (SRS / Airbag)	✓	✓			
SAM-Driver		✓			
SAM-Passenger		✓			
SAM-Rear		✓			
RevETR-FL	✓	✓			
RevETR-FR	✓	✓			
OCP		✓		✓	
LCP (Lower Control)		✓			
UCP (Upper Control)		✓			
HRA		✓			
<b>WSS (Weight Sensing System)</b>	✓	✓		✓	
<b>System Diagnosis</b>		✓			
BCM	✓	✓			

\*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

\*QUICK SERVICE: Perform "Service Reset" within seconds.

## CLS-class, 219-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
PTS (Parktronic System)		✓			
SCM (Steering Column Module)		✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
TLC (Trunk Lid Control)	✓	✓			
HS (Seat Heater)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

## CL-class, 215 (nonCAN) with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
KG	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

## CL-class, 215 (nonCAN) with \*QUICK SERVICE & \*SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – TELE AID		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
KLA (Climate Control)	✓	✓			
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

## CL-class, 215-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
<b>ME 9.7</b>	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓			
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA	✓	✓			
HLICM-L (Left headlamp)	✓	✓			
HLICM-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓			
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓			
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
System Diagnosis		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

## CL-class, 215-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

**CL-class, 215-CAN** with \*QUICK SERVICE & \*SHORT TEST (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

## CL-class, 216 with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
<b>ME 9.7</b>	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
<b>EGS 722.9</b>	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
SGR (Radar sensors control unit)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	✓	✓			
ABC		✓			
EPB (Electronic parking brake)	✓	✓			
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
XALWA-L (Left headlamp)	✓	✓			
XALWA-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-Driver	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
COU – ZBE (Central operating unit)	✓	✓			
HBF (Rear control field / panel)		✓			
System Diagnosis		✓			
BNS (Vehicle power supply control module)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

## CL-class, 216 with \*QUICK SERVICE & \*SHORT TEST(continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)		✓			
DS-FR (Front Right Dynamic Seat)		✓			
DSP (Pneumatic pump for Dynamic Seat)		✓			
MKL-HL (Rear left Multicontour backrest)		✓			
MKL-HR (Rear right Multicontour backrest)		✓			
TLC (Truck lid control)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)	✓	✓		✓ (Service reset)	
NSA (Night View Assist)	✓	✓			
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
RFK (Backup camera)	✓	✓			
COMAND		✓			
ZAN (Central Display)		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KBE-H (Rear A/C operating unit)	✓	✓			
STH (Stationary Heater)		✓			

## R-class, 251 with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
CDI 5		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENR (Electronic level control)	✓	✓			
AIRmatic (Suspension)	✓	✓			
ESP	✓	✓			
TPC (Tire Pressure)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)		✓		✓	
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA (Headlamp)		✓			
SAM-Front	✓	✓		✓	
SAM-REAR	✓	✓		✓	
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear control field / panel)	✓	✓			
System Diagnosis		✓			

## R-class, 251 with \*QUICK SERVICE & \*SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat heater)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated steering wheel)	✓	✓			

## M-class, 163 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
TC / VG	✓	✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
AAM (All Activity Module)	✓	✓		✓	
EAM (Extended Activity Module)	✓	✓		✓	
DAS (Drive Auth. System)	✓	✓			
LCP (Lower Control)	✓	✓			
HRA	✓	✓			
SEM (Security Module)		✓			

## M-class, 163 with SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL (Cellular Telephone)		✓			
VCS		✓			
SOUND		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC (Tempmatic Air conditioning)	✓	✓	✓ (partial version)	✓ (partial version)	
STH (Stationary Heater)	✓	✓			

## M-class, 164-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
CDI 3		✓			
CDI 4		✓			
TC / VG		✓			
ISM	✓	✓	✓		
HAQ		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓		✓	
TPC (Tire Pressure)		✓			

## M-class, 164-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA		✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear Control Field)	✓	✓			
System Diagnosis		✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)		✓			
SVMCM		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat Heater)	✓	✓			

## M-class, 164-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

## G-class, 463

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
HFM	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM	✓	✓		✓	
VGS		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			

## G-class, 463 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA	✓	✓			
RFL		✓			
EIS	✓	✓		✓	
OCP		✓		✓	
UCP		✓			
SAM-FRONT		✓		✓	
SAM-REAR		✓		✓	
AHE		✓			
VR	✓	✓			
SVMCM		✓			

  

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL (Cellular Telephone)		✓			
VCS		✓			
SCM		✓			
APS		✓			
TV		✓			
TELE-AID		✓			

  

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1		✓			
DCM 2		✓			
ESA – Driver		✓			
ESA – Passenger		✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## GL-class, X164-CAN with \*QUICK SERVICE & \*SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓	✓	✓	
CDI 3		✓			
CDI 4		✓			
TC / VG		✓			
ISM	✓	✓	✓		
HAQ		✓			
DTR		✓			
FSCU(Fuel pump)		✓			

  

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓		✓	
TPC (Tire Pressure)		✓			

## GL-class, X164-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA		✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear Control Field)	✓	✓			
System Diagnosis		✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)		✓			
KG (Keyless Go)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat Heater)	✓	✓			
ERA (Electric fold-down backrest system)	✓	✓			
REDC (Rear-end door closing control module)	✓	✓			

## GL-class, X164-CAN with \*QUICK SERVICE & \*SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

## SPRINTER 901,902,903,904,905

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
CDI 1	✓	✓		✓	
CDI 1.7	✓	✓			
CDI 2	✓	✓	✓		
IFI	✓	✓			

  

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			

  

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

  

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
APS		✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

## SPRINTER 906-CAN with \*QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CDI 4		✓			
EGS 722.9	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓			
VG	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
TPC		✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAG(Trailer connection unit)		✓			
OCP(Overhead control panel)		✓			
EIS(Electronic ignition switch)	✓	✓			
KE(Keyless Entry)		✓			
HRA(Headlamp range adjustment)	✓	✓			
SCM(Steering column module)		✓			
UCP(Upper control panel)		✓			
SAM-F	✓	✓			
AB(Airbag)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)		✓		Service Reset	
MTCO(Modular tachograph)		✓			
PTS(Parktronic system)		✓			
AGW(Audio gateway)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
STL(Left electric sliding door)		✓			
STR(Right electric sliding door)		✓			
DCM(Door control module)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC(Automatic air conditioning)	✓	✓			
PTC(Electric heater booster)	✓	✓			
STH(Auxiliary heater)	✓	✓			
ZHZ(Heater booster)	✓	✓			

## VANEO

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ECM/MSM (Engine Control Monolith)	✓	✓			
CDI 1 (Common Rail Diesel Injection)	✓	✓			
ACS (Automatic Clutch System)		✓			
FTC (Front Transmission Control)		✓			
GRM (Gear Recognition Module)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ESM	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Thief Alarm)	✓	✓			
DAS (Drive Auth. System)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

## VITO (638)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 1 (Common Rail Diesel Injection)	✓	✓			
CDI 2(Common Rail Diesel Injection)	✓	✓	✓		
IFI	✓	✓			

  

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			

  

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

  

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
APS		✓			

  

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

## VITO / VIANO (639)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 3 (Common Rail Diesel Injection)	✓	✓			
ETC	✓	✓			
ESM	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP	✓	✓			
ENR	✓	✓			
TPC	✓				

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
OCP		✓			
UCP	✓	✓			
SAM	✓	✓			
EIS		✓			
SDE-H		✓			
AAG		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)		✓		Service Reset / Oil Quality	
APS		✓			
PTS	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger		✓			
ESD-L (left electric sliding door)		✓			
ESD-R (right electric sliding door)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			
REAR-AC	✓	✓			
PTC(Electric heater booster)	✓	✓			

## VARIO

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 1 (Common Rail Diesel Injection)	✓	✓			
CDI 2(Common Rail Diesel Injection)	✓	✓	✓		
IFI	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

The information contained herein is the exclusive property of Autoland Scientech® and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Autoland Scientech®. Autoland Scientech® reserve the right to make any change without notice. The trademarks mentioned belong to the owners.